

## Flip Top Cover (V9 version) Installation Guide



1.  
Turn over the PS2 console.



2.  
Remove those 6 screw (red circles) covers & screws.



3.  
Turn over again and remove the cover from the back carefully.



4.  
The PS2 should now be displayed as above.



5.  
Unscrew the 2 tiny screws on the CD/DVD drive tray cover.



6.  
Note that there are two plastic arms that attached the tray cover. You can use a stick to detach the arms



7.  
Lift the cover off.



8.  
Remove the white disc from the tray cover & insert it in the Flip-Top lid.



9.  
Attach the Flip Top Cover to the console carefully



14.  
Turn over the PS2 & replace screw covers & screws.



15.  
After replace those 6 screws, now you can enjoy it!